Metro Fixed Mounting Installation Instructions

Warnings

CAUTION—risk of fire and this product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Suitable for wet locations.

Mounting orientation must have light source facing down.

Electrical service must be disconnected during installation.

Proper grounding is required to protect against shock and proper operation.

Tools Required

5/32" Allen wrench 9/64" Allen wrench 15mm wrench Wiring tools and connectors

Installation

Step 1: Turn off power to location.

Step 2: Ensure bolt patten matches dimension shown in Figure A.

Step 3: Install fixed mounting bracket to pole using supplied (2) 1/4"-20 flat head screws as shown in Figure A. Poles supplied by others will require 1/4"-20 thread inserts supplied by others.


Step 4: Feed power cable through wire hole in pole.


Step 5: Attach fixture to fixed mounting bracket using supplied (4) 8-32 socket cap screws with Belleville washers as shown in Figure B.


Step 6: Push wire through cordgrip on fixed mounting bracket and tighten to secure.

Step 7: Make wire connections as shown below in Figure C. If 0-10V dimming is not required, terminate ends from driver.

Step 8: Turn power back on to location.









Structura, Inc. | 9635 Widmer Rd., Lenexa, KS 66215 | 913.390.8787 | www.structura.com

structura